

E-Z ACCESS® INSTALLATION INSTRUCTIONS

For use with ½" thick sheet rock. Back of panel has one large bracket (top) and one small bracket (bottom). Install with large bracket to the top of cut out. Engage large bracket in cut out and lift upwards until small bracket enters bottom of cut out. Slide panel down until the small bracket is secured on the sheet rock.

Description	O.D. Size		Cut Out Size	
	W	H	W	H
6"x6" Access Panel	8"	8"	6"	6"
12"x12" Access Panel	14"	14"	12"	12"
14"x14" Access Panel	16"	16"	14"	14"

* Door should not be installed near any existing/potential heat source or open flame.
As with any building product you should consult local building/fire codes.